

FEATURES

- Real-time, high-quality encoding of full motion video for video-over-IP applications
- Standards-based, H.264 algorithms (HP/MP/BP)
- Resolutions up to 1080p
- Supports DVI-I (Digital/ Analog) Formats
- Transmit video at rates as low as 64Kbps, up to 20Mbps
- RTP/UDP and TS/UDP Protocols
- Video/Audio/Data multiplexing IAW MPEG-2 Transport Standard
- MISB-Compliant
- Fully configurable network interface
- Encoder Latency <50ms
- Stereo/dual-channel audio inputs
- MPEG-1 Layer II Audio Compression
- Ethernet User Data
- IRIG-B Overlay
- Remote Set-up via Switch/ Control Module
- Multi-channel Packaging



The Model VHE965 DVI-I Video Encoder Module is part of Delta's 9600 Series Video Processing Chassis. The module is a network appliance designed to compress DVI/HDMI or DVI/RGBHV video for transmission over IP networks. The VHE965 provides a practical, cost-effective means to add High Definition (HD) digital and analog sensors to new or existing IP networks. The module can be combined with other 9600 series modules in Delta's Video Processing Chassis (VPC) to support video-over-IP applications with diverse video sources. The VPC supports encoding and decoding of HD/SD-SDI, Composite, and DVI/HDMI video formats for ground stations, operations centers, classrooms, or flight testing.

Utilizing industry-standard H.264 compression, along with flexible adjustments for video resolutions, compression parameters, and network settings, the VHE965 can be configured to deliver high-quality video over any network. The unit is easily configured via the Ethernet port. Audio and user-data channel multiplexing provide for single-stream transmission. The VHE965 is compliant with most off-the-shelf video players.

A division of Delta Information Systems, Inc.

300 Welsh Road, Building 3 • Horsham, PA 19044-2294 • Tel (215) 657-5270 • Fax (215) 657-5273 • www.deltadigitalvideo.com

Questi prodotti sono distribuiti e supportati in Italia da:

**Instrumentation
Devices**

Instrumentation Devices Srl

Via Acquanera 29 - 22100 COMO (Italy)

ph +39 031 525 391- fax +39 031 507 984

info@instrumentation.it - www.instrumentation.it

MODEL VHE965

9600 SERIES: DVI-I VIDEO ENCODER MODULE

VIDEO INPUT

Ports One
Format DVI/HDMI; RGBHV; RGsB
Connector DVI-I

VIDEO COMPRESSION

Algorithm H.264
Format HP/MP/BP
Resolutions 1080p/720p/1080i/480i/576i
Scaling HH/HV/HH-HV
Frame Rate 25/29.97/30/50/59.94/60
GOP Structure Inter/Intra; Infinite/Variable Size

TRANSPORT STREAM

Ports One
Protocol MPEG-2 Transport Stream
RTP
Data Rate 64Kbps to 10Mbps
Format 10/100 Ethernet IP
Configuration DHCP or Static Address
Selectable Ports
Auto Sense Full/Half Duplex
Unicast/Multicast

USER DATA INTERFACE

Ports One
Protocol Clear/KLV
Format Ethernet

CONTROL

Ports One
Format TCP/IP
Protocol Delta's 3-character mnemonics/HTML

AUDIO INPUT

Ports One
Channels None, Left, Right, Stereo
Format Balanced (Line Level)
Levels 2.8Vp-p (1Vrms)
Impedance 10K Ohms
Connector 3.5mm

AUDIO COMPRESSION

Algorithm One
Format MPEG-1 Layer I/II
Sample Rates 8K/16Ksps
Sync Lip synchronized with video

ENVIRONMENTAL

Temp (Op) -20°C to +60°C
Temp (Storage) -55°C to +85°C
Humidity 5%-95% RH, non-condensing

POWER

Volts +12VDC
Watts 7W

SIZE

Chassis Compatible with 9600 VPC (16-Slot) & 9680 VPC (8-Slot)



©2015 Delta Information Systems, Inc.
All rights reserved. Revision 0211

A division of Delta Information Systems, Inc.

300 Welsh Road, Building 3 • Horsham, PA 19044-2294 • Tel (215) 657-5270 • Fax (215) 657-5273 • www.deltadigitalvideo.com

Questi prodotti sono distribuiti e supportati in Italia da:



Instrumentation Devices Srl

Via Acquanera 29 - 22100 COMO (Italy)

ph +39 031 525 391- fax +39 031 507 984

info@instrumentation.it - www.instrumentation.it