

Via Acquanera 29, 22100 COMO (Italy) tel. +39.031.525391 - fax +39.031.507984 - info@instrumentation.it



4-160-1201

Accelerometer, Side Exit



Applications

- Light Industrial
- Gear Boxes
- Motors
- Bearing Housing
- Pumps

Features

- Two-wire, Current Driven
- Hermetically Sealed
- Electrical Isolated
- Single-Point Mounting
- Integral Cable Option

Description

The 4-160-1201 side exit accelerometer is designed for applications requiring a low profile sensor. Ideal for use in multi-point experimental or light industrial vibration monitoring applications.

The two-wire current loop operating principle permits very long interconnecting cables to be used where necessary and at minimum expense since standard screened pair (or multi-pair) cables may be used. The sensor is mounted by means of a single 1/4-28 captive bolt.

The piezoelectric sensor and amplifier are contained within an inner metal enclosure which is electrically and thermally insulated from the outer stainless steel body. This arrangement prevents ground loops and minimizes the effects of thermal shocks and base strain. The inner enclosure is connected to the 0V of the two-wire system and is therefore an effective electrical screen. External connections are made via a side exit integral cable or electrical connector.



4-160-1201 Accelerometer, Side Exit

Performance Specifications

Operation Voltage/Current: 18 to 28 VDC constant current

source of 2-4 mA

Outut Signal: 100 mV/g Dynamic Range: $\pm 50 \text{ g peak}$

Frequency Range: 2 Hz to 3 kHz (±5%)

1 Hz to 7 kHz (±10%) 0.5 Hz to 10 kHz (±3 dB)

Transverse Sensitivity: Less than 5%

Amplitude Linearity: ±1% or better

Temperature Sensitivity: Less than 5% to +250°F (+121°C)

Residual Electrical Noise: Less than 0.1 mg

(2 Hz to 21 kHz)

Signal Transmission: 2 wire system, electrically isolated

from body up to 500 VAC

Ouput Impedance, Max.: <100 ohm

Environmental

Acceleration Limit

Vibration:±50 g, peakShock:5,000 g, peak

Temperature

Operational: -58°F to +250°F (-50°C to +121°C) **Storage:** -67°F to +302°F (-55°C to +150°C)

Environmental Sealing: Sealed to IP67

Mechanical

Resonant Frequency: 21 kHz

Mounting:1/4-28 captive boltMounting Torque:2 to 5 ft. lbs.Weight:5 oz. without cableCase Material:316L stainless steel


Optional Accessories


- 1. Mating Connector P/N 619571-1004
- Cable assembly P/N 780400-91-XXXX (XXXX indicates length in inches e.g.: 10 ft cable = 120 inches is P/N 780400-91-0120).
 Assembly includes mating connector to prepared wire.

Ordering Information

Mating connectors and cable assemblies are not furnished and must be ordered separately. In keeping with CEC's policy of continuing product improvement, specifications may be changed without notice. See table for type numbers and available configurations.

NOTE: For submersed applications down to 100 ft., use model 4-160-2201-0X.





| Type | Connection |
|---------------|------------------------|
| 4-160-1201 | Side Connector |
| 4-160-2201-01 | Integral 10 ft. cable |
| 4-160-2201-02 | Integral 30 ft. cable |
| 4-160-2201-03 | Integral 50 ft. cable |
| 4-160-2201-04 | Integral 100 ft. cable |

CEC Vibration Products • 746 Arrow Grand Circle • Covina, California 91722 • USA (626) 938-0200 • (800) 468-1345 • Fax: (626) 938-0202 • www.cecvp.com

