ID/JX-P420 SERIES 4 to 20 mA OUTPUT

The **ID/JX-P420** series linear position measuring transducer is a low cost device for use in moderate duty applications in hostile wet or dry environments. The chemical resistant thermoplastic case of the transducer provides IP-65 (NEMA 4X) ingress protection for applications where exposure to washdown, rain, oil and other liquids may occur. The sealed case is achieved through the use of o-rings and a low friction shaft seal. An integral dust wiper insures that the wire rope stays clear of debris as it is extracted and retracted. The standard electrical connection includes a sealed bulkhead fitting and multi-conductor electrical cable. An optional connector and mating connector are also available. As a convenience, optional connector locations on the transducer body are offered. The wire rope exit direction may be specified at time of order or may be user adjusted at time of installation.

The **ID/JX-P420** series transducer is a loop powered device with a 4 to 20 mA current output that requires a two wire connection. The transducer, power supply, and current monitor are connected in series. Zero and span

adjustment potentiometers are accessible by removing two sealing screws in the rear of the transducer housing. Zero and span allow for adjustment for a full 4 to 20 mA output at between 50% and 100% of maximum linear travel.


SPECIFICATIONS

GENERAL

Measurement Range	
Sensing Device	Precision Potentiometer
Resolution	Essentially Infinite
Linearity	
2", 2.8", 3.8", 4.7" ranges	±1.0% Full Scale
10" to 25" ranges	±0.5% Full Scale
30" to 80" ranges	±0.25% Full Scale
Repeatability	±0.02% Full Scale
Construction	
Wire Rope	Ø.018 (0.46 mm) Jacketed Stainless Steel
Wire Rope Tension	
Weight	6.7 oz. (190 gm)
Connections	. Electrical cable, or plastic connector
Life	
Ranges to 4.7"	2,000,000 full stroke cycles
Ranges 10" to 25"	500,000 full stroke cycles
Ranges 30" to 80"	250,000 full stroke cycles
ENVIRONMENTAL	
Operating Temperature	25°C to 75°C
Storage Temperature	50°C to 80°C
Operating Humidity	100% R.H. NEMA 4,
	90% R.H. non-condensing NEMA 12
Vibration	15 G's 0.1 ms max.
Shock	50 G's 0.1 ms max.
Ingress Protection	IP-65 (NEMA 4X) or IP-52 (NEMA 12)

ELECTRICAL Output

LEOTINOAL	
Output	. 4 to 20 mA
Load Resistance (Total Loop)	See Graph Below
Excitation Voltage	. 9 to 35 VDC
Minimum Supply Voltage	. (.02 x Load Res.) + 9 VDC
Insulation Resistance	100 Megohms min. at 100 VDC
Zero Set Adjustment Range	0 to 30% of Range
Span Set Adjustment Range	. 80% to 100% of Range
Protection	



FOOTNOTES TO SPECIFICATIONS 1. Supplemental Data section located at end of ID/JX Series pages

MODEL NUMBER CONFIGURATION BASIC CONFIGURATION (FOR ALL RANGES) JX-P420-4 5 6 $(\mathbf{0})$ (7) 9 2 3 8 ID/JX-P420-50-N11-20S-N1C 0 RANGE WIRE ROPE (4) INGRESS PROTECTION (**7**) N.... ... Required Designato2" (50 mm) .2.8" (70 mm) .3.8" (96 mm) 2. N.....Ø.018 (0,45 mm) IP-65 (NEMA 4X) dust and 8 ELECTRICAL CONNECTION LOCATION 2.8 Nylon Jacketed Stainless Steel spraying water protection USE NUMBER DESIGNATORS SHOWN 3.8 IP-52 (NEMA12) dust and (2) WIRE ROPE TENSION **4.7**...... 4.7" (120 mm) dripping liquids 4321 4321 .Standard (5) 0. (See Table A & B for values) .Required Designato 20. WIRE ROPE EXIT DIRECTION **ELECTRICAL OUTPUT POLARITY** (3) (6)25" (640 mm) 25. Use Number designators shown Standard (increasing output 30. .30" (750 mm) as wire rope is extended 40. 40" (1000 mm)50" (1250 mm) Reversed (decreasing output 50. as wire rope is extended 60" (1500 mm) 60. 80 .80" (2000 mm) BODY MOUNT CONNECTOR BULKHEAD FITTING 1=STANDARD LOCATION ELECTRICAL CONNECTION (9 С . Connector with Mating Connector . Connector with <u>No</u> Mating Connector* *Electrical cable with mating connector may be END VIEW к 3 ordered separately as item number $\underline{10248-xM}$ where 'x' is the required length in meters. =STANDARD LOCATION Bulkhead Fitting + 1 m (3') Electrical Cable Bulkhead Fitting + 2 m (6.5') Electrical Cable 2 3. Bulkhead Fitting + 3 m (10') Electrical Cable 4 Bulkhead Fitting + 4 m (13.5') Electrical Cable . Bulkhead Fitting + 5 m (16.5') Electrical Cable 5



