Scanivalve

Features

- Maintains a stable temperature environment for MPS4000 series pressure scanners
- Quick disconnects for electrical and pneumatic I/O
- Rugged IP-54 rated aluminum case
- Available for:

MPS4164 Analog Scanner - NPx or CPx MPS4264 Ethernet Scanner - NPx, CPx, or EPx

General Description

The MPS (Miniature Pressure Scanner) line of Thermal Control Units is designed to provide a controlled temperature environment for MPS4264 series electronic pressure scanners, or MPS4164 analog pressure scanners. The MPS4000 series pressure scanners incorporate temperature compensated piezoresistive pressure sensors which must remain in a controlled temperature environment to provide the most accurate pressure measurement. All MPSTCU's include a rugged anodized aluminum enclosure, single pneumatic connector, mating pnuematic connector, a single electrical/data connector, and breakout cable with flying leads.

The MPSTCU offers an optional heater circuit for use in environments as cold as -60°C. This heater circuit utilizes two 20 watt heaters to keep the MPS4264 scanner within its temperature compensated range (0-70°C). Exceeding the compensated temperature range can induce errors in the pressure measurements.

For higher temperature applications (60-125°C) the Cooling Kit variant of the MPSTCU is required. The cooling kit variant contains the same heater circuit as the heater only MPSTCU variant. With the addition of the cooling kit, the MPSTCU can keep the MPS in the compensated range while the environmental temperatures range from -60°C to 125°C. Approximately 3.0 CFM of 23°C cooling air is required to properly cool the MPS while subject to the 125°C environment.

The electrical connector on the for the MPS4264T-CU (Ethernet) is a 17 contact M12 series connector which provides module power, heater power, scan triggering, and Ethernet data.



Model MPSTCU

Thermal Control Unit

The electrical connector on the MPS4164TCU (analog) is a 19 contact Bendix PT series connector which provides module power, heater power, and analog addressing.

The pneumatic connector on all MPSTCU's is a Scanivalve 70MPS series connector. These features make for easy use and adaptability when implementing the MPSTCU into a complex system.

Application

Thermal Control Units are most commonly utilized in flight test, automotive, wind turbine, wind tunnel, and engine test applications where temperatures tend to vary and are often extreme.

Thermal Control Units may also be used anywhere a stable temperature environment is not available for MPS pressure scanners. Although the environmental temperatures are within the compensated range of the scanner, a Thermal Control Unit can be used to improve measurement accuracy and limit any effects from temperature.

Thermal Control Units also provide a ruggedized enclosure to protect the scanner's components from moisture, dust, debris, and other contaminants that could harm the scanner.

ISO 9001:2015 CERTIFIED



Instrumentation Devices Srl Via Acquanera 29 - 22100 COMO (Italy) ph +39 031 525 391- fax +39 031 507 984 info@instrumentation.it - www.instrumentation.it

Specifications (MPS4264TCU for NPx or CPx)

Mechanical Capacity:	MPS4264/64CPx MPS4264/64NPx	
Case Material:	6063 Anodized Aluminum	
Operating Temperature Range:	-60°C to +125°C*	
Pneumatic I/O:	70 Port connector with 0.063" tubulations (standard) or 70 Port connector with 0.040" tubulations** (optional)	
Electrical I/O:	17 contact M12 Series	
Heater Rating:	Two 20 watt heaters	
Power Required:		
Without heater: With heater option:	9-36Vdc, 3.5W 20-30Vdc, 45W	
Cooling Air Required (125°C Environment): 3.0 CFM		

Temperature Sense: 4 wire RTD

Mounting Position: Any

Ingress Protection: IP-54 rating

Shock and Vibration: MIL-STD-810G Category 24

Weight:

(Including MPS Scanner and connector) MPS4264TCU 1.97 lbs. (.89 kgm)

Minimum Environmental Pressure: MPS4264TCU 0.5psia

Ordering Information

MPS4264TCU-X

Where **X** is:

-1 MPS4264TCU with Cooling Kit and Heater -2 MPS4264TCU with Heater Only -3 MPS4264TCU no Heater or Cooling Kit

*Scanivalve recommends use of the MPS4264TCU with Cooling Kit in environments above 60°C. 3.0 CFM of 23°C cooling air is required at 125°C. **Px inputs are 0.040" tubulations. CAL, REF, CALCTL, PXCTL and PURGE are 0.063" tubulations





MPS4264TCU-2 Thermal Control Unit



Specifications (MPS4164TCU for NPx or CPx)

Mechanical Capacity:	MPS4164/64CPx MPS4164/64NPx
Case Material:	6063 Anodized Aluminum
Operating Temperature Range:	-60°C to +125°C*
Pneumatic I/O:	70 Port connector with 0.063" tubulations (standard) or 70 Port connector with 0.040" tubulations** (optional)
Electrical I/O:	PT06A-14-19P
Heater Rating:	Two 20 watt heaters
Power Required:	
Without heater: With heater option:	±15Vdc @120mA 20-30Vdc, 45W
Cooling Air Required (125°C Environment): 3.0 CFM	
Temperature Sense:	4 wire RTD

Mounting Position: Any

Ingress Protection: IP-54 rating

Shock and Vibration: MIL-STD-810G Category 24

Weight:

(Including MPS Scanner	and connector)
MPS4164TCU-1	1.97 lbs (.89 kg)
MPS4164TCU-2	1.77 lbs (.80 kg)
MPS4164TCU-3	1.62 lbs (.73 kg)

Minimum Environmental Pressure: MPS4164TCU 0.5psia

Ordering Information

MPS4164TCU-X

Where X is:

- -1 MPS4164TCU with Cooling Kit and Heater
- -2 MPS4164TCU with Heater Only -3 MPS4164TCU no Heater or Cooling Kit

*Scanivalve recommends use of the MPS4164TCU with Cooling Kit in environments above 60°C. 3.0 CFM of 23°C cooling air is required at 125°C.

**Px inputs are 0.040" tubulations. CAL, REF, CALCTL, PXCTL and PURGE are 0.063" tubulations



-1 MPS4164TCU THERMAL CONTROL UNIT, HEATER AND COOLING KIT (SHOWN) -2 MPS4164TCU THERMAL CONTROL UNIT, HEATER ONLY -3 MPS4164TCU THERMAL CONTROL UNIT, NO HEATER/COOLING



MPS4164TCU-2 Thermal Control Unit



Specifications (MPS4264TCU for EPx)

Mechanical Capacity:	MPS4264/64EPx
Case Material:	6063 Anodized Aluminum
Operating Temperature Range:	-60°C to +125°C*
Pneumatic I/O:	70 Port connector with 0.063" tubulations (standard) or 70 Port connector with 0.040" tubulations** (optional)
Electrical I/O:	17 contact M12 Series
Heater Rating:	Two 20 watt heaters
Power Required:	
Without heater:	18-36Vdc, 5.5W (Required to operate electric valve)
With heater option:	20-30Vdc, 45W
Cooling Air Required (125°C Environment): 3.0 CFM	
Temperature Sense:	4 wire RTD
Mounting Position:	Any

Ingress Protection: IP-54 rating

Shock and Vibration: MIL-STD-810G Category 24

Weight:

(Including MPS Scanner and connector) MPS4264TCU/EPx 2.93 lbs. (1.33 kgm)

Minimum Environmental Pressure:

MPS4264TCU/EPx 0.5psia

Ordering Information

MPSTCU Electric Valve - X

Where X is:

-1 MPS4264TCU with Cooling Kit and Heater -2 MPS4264TCU with Heater Only

-3 MPS4264TCU no Heater or Cooling Kit

*Scanivalve recommends use of the MPS4264TCU with Cooling Kit in environments above 60°C. 3.0 CFM of 23°C cooling air is required at 125°C. **Px inputs are 0.040" tubulations. CAL, REF, CALCTL, PXCTL and PURGE are 0.063" tubulations

Dimensions Inches [mm]



Scanivalve Headquarters

1722 N. Madson Street Liberty Lake, WA 99019 Tel: 509-891-9970 800-935-5151 Fax: 509-891-9481 e-mail: scanco@scanivalve.com www.scanivalve.com Printed in USA

[©]2019, Scanivalve Corp.



Scanivalve.com

1905

Instrumentation Devices Srl Via Acquanera 29 - 22100 COMO (Italy) ph +39 031 525 391- fax +39 031 507 984 info@instrumentation.it - www.instrumentation.it